




- This watch is solar-powered. Expose the dial to light and use it sufficiently charged.
- To see details of charging time, specifications and operations, refer to the instruction manual:  B876 instruction manual  B877 instruction manual

Component identification



- Actual appearance may differ from the illustration.
- The crown has two positions when pulling it out.
- Refer also to our web page for detail of usage of the scale and bezel on the watch.

(<http://www.citizenwatch-global.com/support/pdf/enhanced/e.pdf>)

Setting the time

- 1. Pull the crown out to position 2 when the second hand points 0 second.**

The second hand stops.

- 2. Rotate the crown to adjust the 24-hour hand and minute hand.**

- Move the hands 4 or 5 minutes forward and move them back to the right time to set the time more precisely.
- The hour and 24-hour hands move synchronously.

- 3. Push the crown in to position 0 in accordance with a reliable time source.**

The second hand starts moving.

- 4. Pull the crown out to position 1.**

- 5. Rotate the crown clockwise to set the hour hand.**

- Rotate the crown to move the hour hand fully for each portion of hours.
- Change of date indication shows it just became AM. Take care the time set is AM or PM.

- 6. Push the crown in to position 0 to finish the procedure.**

Setting the date

- Do not adjust the date indication while the watch shows 9:00 PM - 1:00 AM. Otherwise, the date indication may change incorrectly thereafter.
- Date indication adjustment is required on the first days of March, May, July, October and December.

- 1. Pull the crown out to position 1.**
- 2. Rotate the crown counterclockwise to set the date indication.**
- 3. Push the crown in to position 0 to finish the procedure.**

Using the local time

You can move the hour hand in the 1-hour increments to indicate a time different from that of the 24-hour hand.

- 1. Pull the crown out to position 1.**
- 2. Rotate the crown clockwise to set the hour hand.**
 - Rotate the crown to move the hour hand fully for each portion of hours.
 - Change of date indication shows it just became AM. Take care the time set is AM or PM.
 - Set the date after the adjustment if needed.
 - The hour hand and date indication move synchronously. The indication may be conflicting with that of the 24-hour hand.
- 3. Push the crown in to position 0 to finish the procedure.**

To set the hour hand back

Adjust the hour hand to the same time as that indicated by the 24-hour hand. Adjust the date indication following [Setting the date](#) after that.