

ACCUTRON


EVOLUTIONARY

ACCUTRON ELEVATION WATCH MANUAL

FEATURES


- **Resonator Technology:** The proprietary Accutron Caliber NM33 features a three-prong tuning fork that vibrates at 262 kHz – eight times traditional quartz for unmatched accuracy within seconds per year.
- **Sweeping Seconds Hand:** Features a visually fluid sweeping seconds hand that moves at 16 beats per second, creating a smooth and continuous motion.

COMPONENT IDENTIFICATION



SETTING THE TIME

1. **Pull out the crown**
Pulling out the crown stops the hands.
2. **Rotate the crown to set the time**
The hour and minute hands will rotate as you turn the crown. Adjust the hands to your desired time.
3. **Push in the crown**
Pushing the crown in restarts the hands.



ABOUT THE BATTERY

Your Accutron includes a battery with an approximate lifespan of 3 years. Within the watch’s warranty period, Accutron will cover battery replacement.

FREQUENTLY ASKED QUESTIONS

- **How should I store my Accutron timepiece?**
When storing your Accutron timepiece, the watch should be flat, with the dial facing upward, in a place that is not exposed to high or low temperatures or high humidity.
- **Does magnetism affect my Accutron timepiece?**
The resonator movement that powers your Accutron timepiece includes magnets and metal parts that can be affected by magnetic fields, which may affect the accuracy of the watch.
- **Will impacts or shocks affect my Accutron timepiece?**
Your Accutron timepiece’s accuracy and ability to function may be affected by strong impacts or shocks. Avoid exposing the watch to sudden impacts and do not place the watch on a surface with continuous vibration.
- **What is the water resistance of my Accutron timepiece?**
The “Water Resistant” marking on your Accutron indicates that it is suitably only for accidental moisture exposure, such as light rain or a small splash. The watch cannot be worn bathing, swimming, or for other aquatic or marine activities.

AFTER SALES SERVICE AND REPAIR

- **Battery Replacement**
Do not attempt to replace the battery yourself. Consult with an authorized Accutron Service Center to have your battery replaced. Accutron will cover battery replacement within the watch’s warranty period.
- **Service and Repair**
Your Accutron timepiece should only be serviced or repair by an authorized Accutron Service Center. To have your timepiece serviced or repaired, consult an authorized Accutron Service Center.

WARRANTY



Your Accutron timepiece is covered by our 5-year limited warranty and only goes into effect once it is fully registered. To activate the warranty, scan the QR code or click [here](#).

The warranty covers parts of the watch that have failed due to defects in materials or workmanship that occur under normal use. Accutron, at its discretion, may replace your watch with a comparable watch.

Any service, maintenance, or repairs which require the opening of the case must be performed by an authorized Accutron Service Center. Improperly or incorrectly performed service, maintenance, or repairs void the warranty.