

# MODELS AV\*\*\* CALIBRE 2100 SERIES

Mvmt. Cal. No. E210

## FEATURES

- Light Powered
- Rechargeable Battery
- 12-Hour Chronograph
- Alarm
- Power-Reserve Meter

## BENEFITS

- Environmentally Clean Energy Source
- No Battery Changes
- 1/5 Second Sweep Hand
- Sounds at Set Time Every 12 Hours
- Indicate Charge Level of Energy Cell

 Please view our interactive setting instructions @ [www.citizenwatch.com](http://www.citizenwatch.com)



**IMPORTANT NOTE:** After a complete loss of power, a sharp knock, static electricity or magnetism, you may find your watch is not operating correctly. If this occurs, you will need to fully recharge your watch and perform the ALL RESET procedure as outlined below.

**NOTES:** Your watch may feature a screw down crown. If so, unscrew the crown to release it from the case before performing the ALL RESET procedure, setting the time or calendar. Be sure to screw the crown into the case after completing any of these procedures.

## ALL RESET PROCEDURE

- Your watch may feature a screw down crown at the 3:00 position. If so, unscrew the crown to release it from the case.
- When the second hand reaches the 12:00 position, pull the 3:00 positioned crown out two 'clicks'.
- Simultaneously press and hold the upper left and lower right buttons (B & C) for two seconds and release. NOTE: The upper left button (C) is recessed into the case and will require a narrow object such as the tip of a pair of pointed tweezers.
- The alarm tone will sound and the recharge indicator hand will move to level 3 to indicate the ALL RESET procedure is complete.
- Push the 3:00 positioned crown in two 'clicks' to the closed position next to the case. The charge level will move back and forth and the real time second hand will start to move in one second increments. NOTE: If your model features a screw-down crown, be sure to screw the crown into the case.

## TO SET THE TIME

- When the 'real time' second hand reaches the 12:00 position, pull the 3:00 positioned crown out two 'clicks'.
- Rotate the 3:00 positioned crown clockwise until you see the date start to change. Use this time shown as a night time reference and continue to rotate the crown until your current time is shown. This will ensure the date changes at "night" rather than during the "day".
- Push the 3:00 positioned crown in two 'clicks' to the closed position.

## TO SET THE CALENDAR

**NOTE:** The calendar is based on a 31-day month and therefore must be corrected for each month having less than 31 days.

- Pull the 3:00 positioned crown out one 'click'.
- Rotate the 3:00 positioned crown counterclockwise until the correct date is shown.
- Push the 3:00 positioned crown in one 'click' to the closed position.

## TO SET THE ALARM

When activated (turned on) the alarm will sound at the set time once every 12-hours for approximately 20 seconds. The alarm accuracy may have a variance of 3 to 5 minutes before or after the set time.

- Pull the 7:00 positioned crown out one 'click'.
- Rotate the 7:00 positioned crown clockwise to move the alarm indicator hand 1/2 hour past the desired set time.
- Rotate the 7:00 positioned crown counterclockwise to the desired set time.
- Push the 7:00 positioned crown in one 'click' to the closed position.

## TO ACTIVATE (TURN ON) OR DEACTIVATE (TURN OFF) THE ALARM.

- With the 7:00 positioned crown in the closed position, press and release the crown to move the alarm indicator hand to 'on' or 'off'.
- When the alarm sounds, press and release the 7:00 positioned crown to move the indicator hand to the 'off' position. If the alarm is allowed to ring without manually turning the alarm to 'off', it will sound in another 12 hours.

Note: While the 7:00 positioned crown requires a firm push to turn the alarm on or off, it does not require the effort the chronograph stop/start button requires (upper right button A).

## TO USE THE 12-HOUR CHRONOGRAPH

NOTE: When chronograph timing has reached 12-hours, the chronograph will stop. If this happens you will need to press and release the lower right button (B) to reset the chronograph before commencing new timing.

- Firmly** press and release the upper right button (A) to start the chronograph. The chronograph sweep second hand will start to move in 1/5 second increments.
- Firmly** press and release the upper right button (A) to stop the chronograph.
- Firmly** press and release the lower right button (B) to reset the chronograph.

## POWER RESERVE INDICATOR

This watch features a power reserve indicator to give the user an approximate charge level of the energy cell. The indicator will "jump" levels as the watch is charged or energy is depleted. Approximate charge level indications are shown in the graphics below.

