

BULOVA

MARINE STAR SERIES A CHRONOGRAPH COLLECTION

SETTING THE TIME AND DATE

This 3-subdial chronograph with built-in stopwatch can measure and display time up to 59 minutes/59 seconds and provide timing to 1/1 of a second.

- To set time, pull the crown out to the 2nd position, **C**.
- Turn the crown clockwise to set hour and minute hands.
- To set date, pull the crown out to the 1st position, **B**.
- Turn the crown clockwise to set date.
* If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change on the following day
- After the time and date has been set, push the crown back to the Normal Crown Position, **A**.

READING THE MARINE STAR CHRONOGRAPH

- 1 Minute Hand
- 2 Chronograph Start / Stop Pusher
- 3 24 Hour Hand
- 4 Normal Crown Position
- 5 Chronograph Reset Pusher
- 6 Date
- 7 Small Second Hand
- 8 Chronograph Second Hand
- 9 Chronograph Minute Hand
- 10 Hour Hand



BULOVA


MARINE STAR SERIES A CHRONOGRAPH COLLECTION

USING THE CHRONOGRAPH

This chronograph is able to measure and display time in 1/1 second increments up to maximum of 59 minutes 59 seconds.

Measuring time with the chronograph

1. The chronograph can be started and stopped each time button “2” is pressed.
2. Press button “5” to reset the chronograph and chronograph minute and second hands return to their zero positions.



CHRONOGRAPH RESET (INCLUDE AFTER REPLACING BATTERY)

This procedure should be performed when the chronograph second hand does not return to the zero position after the chronograph has been reset, and including after the battery has been replaced.

1. Pull the crown out to the 2nd position, **C**.
2. Press the button “2” to set the chronograph second hand to the zero position.
* The chronograph hand can be advanced rapidly by continuously pressing button “2”.
3. Once the hands have been zeroed, return the crown to its Normal Crown Position, **A**.
* Do not push crown to normal position while the chronograph second hand returns to zero position. It stops on the way when crown are returned to normal position and its position is recognized as zero position.



98A278jn,